

# LED-2755 INSTRUCTION



1. Remove front nose from hood.



2. Remove the oem light assembly



3. Cleaning the front nose



4. Reinstall nose to hood, then install LED-2755 light frame to nose.

5. Install the LED lights in same direction to assure the wiring tabs are all facing the same way, mount front bezels using screws to hold lights in place, and tighten screws equally.

Connect wiring harness, red wire to positive, black wire to negative.